# T-shirt

You need: A print of this pattern, fabric, scissors, velcro (or something else you want to use for closing), needle and thread (or a sewing machine).

Level 3

FRONT

1 2 3 4 5 6 7 8 9 10 cm

rubensbarn®
Born in Sweden

BACK x2

**ADVANCED:
OPTIONAL FRONT LINING**

**ADVANCED:
OPTIONAL BACK LINING**

1 2 3 4 5 6 7 8 9 10 cm

• rubensbarn® •
Born in Sweden